Flood & Temperature Sensor

Set Up Your Flood & Temperature Sensor

1 **Choose a Location**

Common areas include under the sink, behind a toilet, or near the water heater.

2 **Pair the Sensor**

From the Panel home screen, select Settings (☰) → Devices → Add Device (+) → Water.

Press the button on the bottom of the Sensor to trigger the device.

3 **Name the Sensor**

Name your Sensor and place it in your decided location with the underside facing the floor.

4 **Complete Setup**

Go back to the panel and press, “Done” on the bottom right screen.

Your Flood & Temperature is now active.

Step 2

Pairing button on the bottom of the Sensor

Flood & Temp. Video Guide

800-574-7798

www.**shieldpro.com**/setup